




Peroxide cured silicone rubber – Optimization of property combinations with Aktisil Q

Author: Nicole Holzmayr



INTRODUCTION


EXPERIMENTAL

RESULTS

SUMMARY


Addition of mineral fillers to silicone rubber


- Cost reduction
- Improved processing
- Optimized mechanical properties



Opposing Properties

For example





Objective

Optimization of Silicone Rubber


HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY





Formulation Components


HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY





Formulation Components

Selection of Polymer Types

HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY





Formulation Components

Selection of Peroxide Type


HOFFMANN
MINERAL®

INTRODUCTION


EXPERIMENTAL

RESULTS

SUMMARY



All results are based on specimens that have been post-cured 4 hours at 200 °C.



Formulation Components

Filler: Aktisil Q

HOFFMANN
MINERAL®

INTRODUCTION


EXPERIMENTAL

RESULTS

SUMMARY

12,5 phr
resp.
25 phr

Aktisil Q - Neuburg Siliceous Earth, methacrylic functionalized
results in an excellent compression set i.a. in VMQ



Selection of Results


HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY






Results

HOFFMANN
MINERAL®

Elastosil R 401



Hardness With and Without Filler Addition

**HOFFMANN
MINERAL®**

INTRODUCTION


EXPERIMENTAL

RESULTS

- Elastosil R 401

SUMMARY

	Curing Agent C6	Perkadox BC-40S-ps
100 phr Elastosil R 401/50	46 Shore A	44 Shore A
100 phr Elastosil R 401/40 + 12.5 phr Aktisil Q	39 Shore A	39 Shore A
100 phr Elastosil R 401/40 + 25 phr Aktisil Q	44 Shore A	43 Shore A



Tear Resistance (Trouser Tear) and Compression Set

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 401](#)
- [Curing Agent C6](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 401](#)
- [Curing Agent C6](#)

SUMMARY





Tear Resistance (Trouser Tear) and Compression Set

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 401](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 401](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Reduced Compound Costs by Using Aktisil Q in Elastosil R 401

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

• Elastosil R 401

SUMMARY






Results

HOFFMANN
MINERAL®

Elastosil R 420



Hardness With and Without Filler Addition



INTRODUCTION


EXPERIMENTAL

RESULTS

- Elastosil R 420

SUMMARY

		Curing Agent C6	Perkadox BC-40S-ps
100 phr Elastosil R 420/50		50 Shore A	50 Shore A
100 phr Elastosil R 420/40	+ 12.5 phr Aktisil Q	41 Shore A	38 Shore A
100 phr Elastosil R 420/40	+ 25 phr Aktisil Q	46 Shore A	44 Shore A



Tear Resistance (Trouser Tear) and Compression Set

**HOFFMANN
MINERAL®**


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 420](#)
- [Curing Agent C6](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 420](#)
- [Curing Agent C6](#)

SUMMARY





Tear Resistance (Trouser Tear) and Compression Set

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 420](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 420](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Reduced Compound Costs by Using Aktisil Q in Elastosil R 420

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

• Elastosil R 420

SUMMARY






Results

HOFFMANN
MINERAL®

Elastosil R 752



Hardness With and Without Filler Addition

**HOFFMANN
MINERAL®**

INTRODUCTION


EXPERIMENTAL

RESULTS

- Elastosil R 752

SUMMARY

	Curing Agent C6	Perkadox BC-40S-ps
50 phr Elastosil R 752/50 + 50 phr Elastosil R 752/70	55 Shore A	56 Shore A
100 phr Elastosil R 752/50 + 12.5 phr Aktisil Q	52 Shore A	51 Shore A
100 phr Elastosil R 752/50 + 25 phr Aktisil Q	59 Shore A	59 Shore A



Tear Resistance (Trouser Tear) and Compression Set

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 752](#)
- [Curing Agent C6](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 752](#)
- [Curing Agent C6](#)

SUMMARY





Tear Resistance (Trouser Tear) and Compression Set

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 752](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Storage in Hot Air, 168 h / 200 °C

Δ Hardness und Δ Elong. at Break

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

- [Elastosil R 752](#)
- [Perkadox BC-40S-ps](#)

SUMMARY





Rebound Elasticity



INTRODUCTION


EXPERIMENTAL

RESULTS

- Elastosil R 752

SUMMARY





Reduced Compound Costs by Using Aktisil Q in Elastosil R 752

HOFFMANN
MINERAL®


INTRODUCTION


EXPERIMENTAL

RESULTS

• Elastosil R 752

SUMMARY





Conclusion


HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY





Conclusion


**HOFFMANN
MINERAL®**

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY




Improved processing behavior due to reduced stickiness



Optimized mechanical properties



Reduction of compound costs




We supply material for good ideas!

HOFFMANN MINERAL GmbH
Muenchener Straße 75
DE-86633 Neuburg (Donau)

Phone: +49 8431 53-0
Internet: www.hoffmann-mineral.de
E-mail: info@hoffmann-mineral.com

Our applications engineering advice and the information contained in this memorandum are based on experience and are made to the best of our knowledge and belief, they must be regarded however as non-binding advice without guarantee. Working and employment conditions over which we have no control exclude any damage claim arising from the use of our data and recommendations. Furthermore we cannot assume any responsibility for patent infringements, which might result from the use of our information.



Test Standards

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

Test	Standard
Mooney Viscosity, ML 1+4	DIN ISO 289-1
Mooney Scorch, ML +5	DIN ISO 289-2
Rotorless Curemeter	DIN 53 529 Part 3
Hardness	DIN ISO 7619-1
Tensile strength	DIN 53 504, S2
Modulus 100 %	DIN 53 504, S2
Elongation at Break	DIN 53 504, S2
Rebound Elasticity	DIN 53 512
Tear resistance	DIN ISO 34-1, A
Compression Set	DIN ISO 815-1, B




Table of Results

Elastosil R 401

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 401/50	R 401/40 + 12.5 phr Aktisil Q	R 401/40 + 25 phr Aktisil Q	R 401/50	R 401/40 + 12.5 phr Aktisil Q	R 401/40 + 25 phr Aktisil Q
Rheology							
Mooney Viscosity, ML 1+4, 120 °C	MU	14	11	13	14	11	13
Mooney Scorch, ML +5, 120 °C	min.	72	20	12	64	17	10
Temperature Curemeter	°C	165			180		
Rotorless Curemeter M _{min}	Nm	0.04	0.03	0.03	0.04	0.03	0.03
Rotorless Curemeter V _{max}	Nm/min.	0.26	0.23	0.26	0.76	0.64	0.76
Rotorless Curemeter t ₉₀	min.	2.7	2.5	2.3	1.0	0.9	0.9
Mechanical properties – post-cured, 4 h / 200 °C							
Hardness	Sh. A	46	39	44	44	39	43
Tensile strength	MPa	13	10	10	12	9.2	9.6
Modulus 100 %	MPa	0.9	0.7	1.0	0.9	0.8	1.0
Elongation at Break	%	679	702	631	647	624	616
Tear resistance	N/mm	9.5	7.8	5.2	8.6	10	7.8
Compression Set, 24 h / 175 °C, 25 % Def.	%	23	18	17	13	11	9,6




Table of Results

Elastosil R 401



INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 401/50	R 401/40 + 12.5 phr Aktisil Q	R 401/40 + 25 phr Aktisil Q	R 401/50	R 401/40 + 12.5 phr Aktisil Q	R 401/40 + 25 phr Aktisil Q
Mechanical properties after storage in hot air (post-cured specimens), 168 h / 200 °C							
Hardness	Sh. A	51	43	48	49	44	49
Tensile strength	MPa	11	8.9	8.5	11	9.5	8.5
Modulus 100 %	MPa	1.3	09	1.3	1.1	1,0	1.2
Elongation at Break	%	560	617	567	614	616	535
Δ Hardness	Sh. A	+5	+4	+4	+5	+5	+6
Δ Tensile strength	%	-17	-15	-16	-9	+4	-12
Δ Modulus 100 %	%	+40	+25	+26	+16	+23	+19
Δ Elongation at break	%	-18	-12	-10	-5	-1	-13




Table of Results

Elastosil R 420

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 420/50	R 420/40 + 12.5 phr Aktisil Q	R 420/40 + 25 phr Aktisil Q	R 420/50	R 420/40 + 12.5 phr Aktisil Q	R 420/40 + 25 phr Aktisil Q
Rheology							
Mooney Viscosity, ML 1+4, 120 °C	MU	17	14	15	17	14	16
Mooney Scorch, ML +5, 120 °C	min.	57	20	11	55	16	8,4
Temperature Curemeter	°C	165			180		
Rotorless Curemeter M _{min}	Nm	0.04	0.03	0.04	0.04	0.03	0.03
Rotorless Curemeter V _{max}	Nm/min.	0.11	0.12	0.18	0.41	0.38	0.51
Rotorless Curemeter t ₉₀	min.	4.4	4.1	3.6	1.5	1.3	1.1
Mechanical properties – post-cured, 4 h / 200 °C							
Hardness	Sh. A	50	41	46	50	38	44
Tensile strength	MPa	10	8.8	8.2	9.5	8.9	7.9
Modulus 100 %	MPa	1.5	1.0	1.3	1.5	1.0	1.3
Elongation at Break	%	651	705	630	642	725	614
Tear resistance	N/mm	17	15	17	17	15	17
Compression Set, 24 h / 175 °C, 25 % Def.	%	33	27	23	19	15	14




Table of Results

Elastosil R 420

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 420/50	R 420/40 + 12.5 phr Aktisil Q	R 420/40 + 25 phr Aktisil Q	R 420/50	R 420/40 + 12.5 phr Aktisil Q	R 420/40 + 25 phr Aktisil Q
Mechanical properties after storage in hot air (post-cured specimens), 168 h / 200 °C							
Hardness	Sh. A	63	47	52	63	47	53
Tensile strength	MPa	9,5	7,8	6,8	8,5	7,5	7,0
Modulus 100 %	MPa	3,2	1,4	1,8	3,1	1,3	1,7
Elongation at Break	%	320	551	464	310	553	496
Δ Hardness	Sh. A	+13	+6	+6	+13	+9	+9
Δ Tensile strength	%	-7	-11	-17	-10	-16	-11
Δ Modulus 100 %	%	+116	+38	+35	+115	+34	+29
Δ Elongation at break	%	-51	-22	-26	-52	-24	-19




Table of Results

Elastosil R 752

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 752/50 + R 752/70	R 752/50 + 12.5 phr Aktisil Q	R 752/50 + 25 phr Aktisil Q	R 752/50 + R 752/70	R 752/50 + 12.5 phr Aktisil Q	R 752/50 + 25 phr Aktisil Q
Rheology							
Mooney Viscosity, ML 1+4, 120 °C	MU	24	24	27	25	25	26
Mooney Scorch, ML +5, 120 °C	min.	64	23	13	66	22	13
Temperature Curemeter	°C	165			180		
Rotorless Curemeter M _{min}	Nm	0.09	0.10	0.11	0.08	0.09	0.10
Rotorless Curemeter V _{max}	Nm/min.	0.32	0.33	0.50	0.79	0.77	0.96
Rotorless Curemeter t ₉₀	min.	4.9	4.5	3.2	1.5	1.5	1.3
Mechanical properties – post-cured, 4 h / 200 °C							
Hardness	Sh. A	55	52	59	56	51	59
Tensile strength	MPa	9.6	8.8	7.3	9.5	8.6	7.8
Modulus 100 %	MPa	1.2	1.1	1.4	1.2	1.2	1.5
Elongation at Break	%	672	698	557	637	631	543
Tear resistance	N/mm	12	12	11	11	13	14
Rebound Elasticity	%	32	34	34	33	35	36
Compression Set, 24 h / 175 °C, 25 % Def	%	24	21	19	14	15	16




Table of Results

Elastosil R 752



INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

APPENDIX

		Curing Agent C6			Perkadox BC-40S-ps		
		R 752/50 + R 752/70	R 752/50 + 12.5 phr Aktisil Q	R 752/50 + 25 phr Aktisil Q	R 752/50 + R 752/70	R 752/50 + 12.5 phr Aktisil Q	R 752/50 + 25 phr Aktisil Q
Mechanical properties after storage in hot air (post-cured specimens), 168 h / 200 °C							
Hardness	Sh. A	64	57	64	61	57	62
Tensile strength	MPa	5.5	6.1	5.2	6.2	7.0	6.1
Modulus 100 %	MPa	1.6	1.3	1.6	1.5	1.3	1.8
Elongation at Break	%	398	532	445	472	532	425
Δ Hardness	Sh. A	+9	+5	+5	+5	+6	+3
Δ Tensile strength	%	-42	-30	-28	-35	-18	-22
Δ Modulus 100 %	%	+42	+17	+16	+27	+16	+16
Δ Elongation at break	%	-41	-24	-20	-26	-16	-22