




Calcined Neuburg Siliceous Earth Silfit Z 91 in silicone rubber


Author: Nicole Holzmayr



Contents

HOFFMANN
MINERAL®

- Introduction
- Experimental
- Results
- Summary



Status Quo

INTRODUCTION

EXPERIMENTAL


RESULTS

SUMMARY

For some formulations in silicone rubber, filler loadings in a range of 25 to 75 phr are asked for.

For some products with low requirements the use of non-surface-treated quartz flour often is sufficient so that using Aktisil Q is not necessary.

Hoffmann Mineral is now able to offer an alternative product for non-surface-treated quartz flour, the **Calcined Neuburg Siliceous Earth Silfit Z 91**, which is more cost-effective than Aktisil Q, on the one hand. On the other hand, it puts forward some advantages over quartz flour.



Objective

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY


Demonstrating the advantages of the

Calcined Neuburg Siliceous Earth **Silfit Z 91**

over the commonly used non-surface-treated quartz flour in silicone rubber regarding

- processing and worker protection
- mechanical properties
- extrusion
- color
- blooming

in combination with bis-(2,4-dichlorobenzoyl)peroxide (**Curing Agent E**) for **extrusion products** resp. 2,5-bis-(t-butylperoxy)-2,5-dimethyl-hexane (**Curing Agent C6**) for **molded parts**.



Fillers, Characteristics

HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

	Particle Size		Oil absorption [g/100g]	Specific surface area BET [m ² /g]	Calcination
	d ₅₀ [μm]	d ₉₇ [μm]			
Silfit Z 91	2.0	10	60	6.5	yes
Quartz flour	3.1	13	31	3.6	no



Preparation and Curing of the Compound

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

- **Mixing**

Open mill Ø 150 x 300 mm

Batch volume: approx. 750 g

Temperature: 20 °C


Mixing time: approx. 13 min.

- **Curing**

Press, 165 °C, 5 min. – for Curing Agent C6


Press, 115 °C, 5 min. – for Curing Agent E


Post-cure, 200 °C, 4 h



Overview

HOFFMANN
MINERAL®





Formulation - Moldings

Curing Agent C6

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL


Moldings

RESULTS

SUMMARY

in phr	Base cpd.	Quartz flour	Silfit Z 91
Quartz flour	-	25	-
Silfit Z 91	-	-	25
Curing Agent C6	1.2		
Elastosil R 401/40	100		







Hardness

HOFFMANN
MINERAL®

DIN 53 505-A, piled-up S2-dumbbells





Tensile Strength

HOFFMANN
MINERAL®

DIN 53 504, S2


INTRODUCTION


EXPERIMENTAL

RESULTS

Moldings

SUMMARY





Elongation at Break

HOFFMANN
MINERAL®

DIN 53 504, S2


INTRODUCTION


EXPERIMENTAL

RESULTS

Moldings

SUMMARY







Tear Resistance

HOFFMANN
MINERAL®

DIN ISO 34-1 Bb (angle test piece with a nick)





Compression Set

24 h / 175 °C

HOFFMANN
MINERAL®

DIN ISO 815-1 B, cooling method A, 25 % defl.


INTRODUCTION


EXPERIMENTAL

RESULTS

Moldings

SUMMARY





Hot Air Aging Change of Tensile Strength

**HOFFMANN
MINERAL®**

DIN 53 508, 168 h / 200 °C


INTRODUCTION


EXPERIMENTAL

RESULTS

Moldings

SUMMARY





Hot Air Aging Change of Elongation at B.

HOFFMANN
MINERAL®

DIN 53 508, 168 h / 200 °C


INTRODUCTION


EXPERIMENTAL

RESULTS

Moldings

SUMMARY







Immersion in IRM 903

Change of Elongation at B.

HOFFMANN
MINERAL®

DIN ISO 1817, 72 h / 150 °C





Formulation - Extrusion

Curing Agent E

HOFFMANN
MINERAL®

INTRODUCTION

EXPERIMENTAL


Extrusion

RESULTS

SUMMARY

in phr	Base cpd.	Quartz flour			Silfit Z 91		
Quartz flour	-	25	50	75	-	-	-
Silfit Z 91	-	-	-	-	25	50	75
Curing Agent E	1.5						
Elastosil R 401/40	100						







Hardness

HOFFMANN
MINERAL®

DIN 53 505-A, piled-up S2-dumbbells







Tensile Strength

HOFFMANN
MINERAL®

DIN 53 504, S2







Elongation at Break

**HOFFMANN
MINERAL®**

DIN 53 504, S2







Tear Resistance

HOFFMANN
MINERAL®

DIN ISO 34-1 Bb (angle test piece with a nick)





Compression Set

24 h / 175 °C

HOFFMANN
MINERAL®

DIN ISO 815-1 B, cooling method A, 25 % defl.


INTRODUCTION


EXPERIMENTAL

RESULTS

Extrusion

SUMMARY







Hot Air Aging Change of Elongation at B.

**HOFFMANN
MINERAL®**

DIN 53 508, 168 h / 200 °C







Immersion in IRM 903

Change of Tensile Strength

HOFFMANN
MINERAL®

DIN ISO 1817, 72 h / 150 °C





Immersion in IRM 903

Change of Elongation at B.

HOFFMANN
MINERAL®

DIN ISO 1817, 72 h / 150 °C


INTRODUCTION


EXPERIMENTAL

RESULTS

Extrusion

SUMMARY





Garvey Extrusion

HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY

Extruder		Schwabenthan Polytest 30 R
Screw diameter	[mm]	30
Process length	[mm]	450
Temperature set point head / zone 1 / zone 2	[°C]	25 / 25 / 25
Screw speed	[rpm]	adjustable
Garvey profile		see picture
Rating figure 1		die swell
Rating figure 2		30° edge
Rating figure 3		surface
Rating figure 4		corners
Objective of extrusion		output 10 m/min.



Garvey Extrusion


HOFFMANN
MINERAL[®]


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY





Garvey Extrusion

Sum of Rating

HOFFMANN
MINERAL®

ASTM D 2230, output 10 m/min.


INTRODUCTION


EXPERIMENTAL

RESULTS

Extrusion

SUMMARY





Blooming

HOFFMANN
MINERAL®

after approx. 7 months, post-cured

INTRODUCTION

EXPERIMENTAL


RESULTS

Extrusion

SUMMARY

	0 phr	25 phr	50 phr	75 phr
Silfit Z 91				
Quartz flour				





CIE-LAB-System


HOFFMANN
MINERAL®


INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY







Color

HOFFMANN
MINERAL®

ISO 7724

● Silfit Z 91 ▲ Quartz flour





Processing and Worker Protection

HOFFMANN
MINERAL®




INTRODUCTION

EXPERIMENTAL


RESULTS


SUMMARY

Abrasivity index*



A-dust (respirable)





Conclusion

INTRODUCTION

EXPERIMENTAL

RESULTS

SUMMARY


Silfit Z 91 is an **excellent alternative** for non-surface-treated quartz flour due to

- ✓ lower abrasivity
- ✓ less formation of dust
- ✓ higher color neutrality and brightness
- ✓ to a large extent comparable mechanical properties
- ✓ equal extrusion properties
- ✓ reduction resp. prevention of blooming (depending on filler loading)

Calcined Neuburg Siliceous Earth:

Material for good ideas





We supply material for good ideas!

HOFFMANN MINERAL GmbH
Muenchener Straße 75
DE-86633 Neuburg (Donau)

Phone: +49 8431 53-0
Internet: www.hoffmann-mineral.de
E-mail: info@hoffmann-mineral.com

Our applications engineering advice and the information contained in this memorandum are based on experience and are made to the best of our knowledge and belief, they must be regarded however as non-binding advice without guarantee. Working and employment conditions over which we have no control exclude any damage claim arising from the use of our data and recommendations. Furthermore we cannot assume any responsibility for patent infringements, which might result from the use of our information.